

Aux kill stomp for Trem/Panneur

www.commonsound.com

non-commercial use only, see license

designed and drawn by Dann Green

2005-11-15

disconnect aux depth 3
and aux LED + from the board.

Wire it as follows:

